

FLIP-DOWN SCREEN VIDEO PLAYERS

(Rear Bunk models only)

-If Equipped


The flip-down LCD screen DVD Video Players are mounted overhead in each of the bunk beds.



The Video Players operate independently so the occupant of one bunk may watch a DVD while the other watches a different DVD. The players each contain auxiliary audio-video inputs for connection of a video game system or other audio-video equipment if desired.

Remote Control and Wireless Sound

- A sensor array above the screen of each Video Player receives command signals from the remote control.



- The sensor array also continuously transmits wireless sound signals for reception on IR wireless headphones.
- See Video Player instruction guide in your InfoCase for remote control instructions and additional information on wireless headphones.


12-Volt Master Power

- The Video Players operate on 12-volt DC current. Turn on the 12-Volt master power (TV) switch shown, located on the back wall of the top bunk.
NOTE: To avoid drain on the 12-Volt house battery, we recommend turning the master power switch off when Video Players will not be in use.



Video Player Power ON/OFF

- Press the POWER button on either the remote control or the unit once to turn the power on. Press the same button to turn the power off.
- Push the open button (located on the front of your screen) and lower the monitor to the desired level. You may also adjust the swivel angle.



To Play DVD

- Insert the DVD label side down (facing you) into the slot on the side of the player. The player will automatically switch to DVD mode. The screen will display the DVD logo and begin to read the disc.
- The DVD may load directly to the main title/menu screen or it may begin to play previews. You may be able to skip previews if desired by pressing the “NEXT” button on the remote until you see the main menu screen.
- When the main menu screen appears, press the PLAY button on the player or ENTER button on the remote control to begin playing the feature, or use the arrow buttons to select the desired entry.
- Volume is adjusted with the +/- buttons on the player or the remote control.



To Play CD Audio (or CD Video)

- The Video Player is also capable of playing CD Audio music and CD Video discs.

- Insert the CD label side down (facing you) into the slot on the side of the player. The player will automatically switch to proper mode to play audio or video CD.


To Connect Game Systems or Other A/V Components

- Plug the audio and video cables of the game




system or component into the audio-video input jacks at the rear underside of the Video Player.

- Switch the game system or component ON.
- Press AV button on Video Player to select. VIDEO 1 or VIDEO 2 input. (The component logo or other indication may appear on screen when proper input is selected).
- Operate game system or component using the component's controller(s).
- See Video Player instruction guide in your InfoCase for more information.



Reading Lights

- Push the light button to turn the reading lights on and off.



Audio-Video System Basic Operation Guide

Flip-Down Screen TV/DVD Video Players

**Rear Bunk models only
-If Equipped**

NOTE: See your InfoCase for specific operating guides for audio and video components.



Part No. 161501-09-020
0902080331

Copyright 2008 Winnebago Industries, Inc.
All rights reserved.